



- 909-546-1160
- hawkeyesales@hawkeyeind.com
- PO BOX 415,
BLOOMINGTON, CA 92316
- WWW.DURATEC1.COM

MAKE YOUR GELCOAT SPRAY LIKE PAINT

FEATURES

- NO DULL SURFACE**
Additive eliminates the need for wax & PVA creating a superior finish.
- ELIMINATES LOW-GLOSS**
Especially areas on the edges of repairs, like the low-gloss “donut” often seen in gel coat repairs.
- BETTER PROFILE**
Flat & smooth profile compared to un-modified gel coat or gel coat with wax & styrene.
- REDUCED POROSITY**
In tooling gelcoat. Improves air release, thus preventing porosity.
- FASTER & EASIER REPAIR**
The air-cure blend created with gelcoat cures fast and hard, creating a shiny smooth surface that is easy to sand.

DURATEC CLEAR HI-GLOSS ADDITIVE

PRODUCT #904-001

DESCRIPTION

With over 30 years of successful use, Duratec Hi-Gloss Additive is the proven leader for post-application gel coat work. Hi-Gloss Additive converts gel coat to air-cure chemistry, leading to a smooth, porcelain-hard surface. Use this product in applications such as complete gel coat resurfacing, plug and pattern manufacturing, and gel coat repair. Blend with the original gel coat to match to desired color. Make gel coat repair come out perfectly every time!

PRODUCT PROPERTIES All time calculations are based on temperatures of 77°F, 25°C Lab tested with Norox 925 MEKP	
Gel time @ 2% MEKP	14-18 minutes
Weight per gallon	8.54 lbs/gal
% Solid Content	52%
% VOC	48%
Wt% HAPs	34%

SAFETY & HANDLING

Duratec Hi-Gloss Additive is extremely flammable. Do not apply near sparks, open flames or heat. Keep area ventilated. Do not smoke. Avoid continuous breathing of vapor. Duratec Hi-Gloss Additive contains ingredients which could be harmful if mishandled. Contact with skin and eyes should be avoided and necessary protective equipment and clothing should be worn. Individuals should wash with soap and water before eating or drinking. All containers should be properly labeled to prevent accidental ingestion or improper disposal. Individuals should reseal any partly used material back in the container. Store under cool, dry conditions and away from open flames and high temperatures.

For more detailed instructions on storage, please see the MSDS sheet.



DURATEC CLEAR HI-GLOSS ADDITIVE

APPLICATION GUIDE | PRODUCT #904-001

PLEASE NOTE

The following use instructions are broad to address multiple applications. We recommend testing for product compatibility with your process. Please contact our Tech Team at (909) 546-1160 with any questions.

Prepare

Temperature should be at least 64°F. Low temperatures extend cure time.

A test blend is recommended, as every blend is unique and the cure must be tested and assured. The cure time of the blend will vary, as every gelcoat is different. Note the cup-gel time.

If repairing, remove or fix any cracked or damaged gelcoat. Grind out cracks down to the laminate. Repair laminate or assure the laminate is sound. We recommend Duratec Vinyl Ester Mold Repair Putty (1800 Series) for laminate repair.

Sand with 180 grit to a few inches outside the repair area. Bevel the edge of the existing gelcoat.

Blend

OPTION #1: 1 part (25%) Duratec 904-001, 3 parts (75%) gelcoat.

Recommended to maximize the hide (opacity). If opacity is not an issue, use option #2.

- 1 Catalyze with full strength MEKP catalyst at 2%, like Norox 925 (about 20 milliliters per quart).
- 2 Spray 3-4 passes over the repair, building up 12-15 mils. Allow at least two minutes between passes. Do not allow the Duratec/gelcoat to cure beyond the sticky/thumbprint stage between coats... usually about 30 minutes at 77°F when sprayed, faster in the cup. Feather the edge of the repaired area.

Once surface cure is sandable (approx. 2-4 hours) sand as outlined below to cut surface and allow full cure.

OPTION #2: 1 part (50%) Duratec 904-001, 1 part (50%) gelcoat.

Recommended for all repairs where opacity is not an issue. Not recommended for dark colors.

- 1 Catalyze with full strength MEKP catalyst at 2%, like Norox 925 (about 20 milliliters per quart).
- 2 Spray at least 2 passes over the repair, building up an additional 8 mils or more to match surface. Be sure to get back onto the first passes while they are sticky. Cover all the previously coated area. Feather the edge of the repaired area.

NOTE: if you are not doing a repair area, and instead covering an entire surface, build up 18+ mils overall, 5-7 mils at a time while allowing out-gassing to occur between passes.

Once surface cure is sandable (approx. 2-4 hours) sand as outlined below to cut surface and allow full cure.

[CONTINUED ON NEXT PAGE]



DURATEC CLEAR HI-GLOSS ADDITIVE

APPLICATION GUIDE | PRODUCT #904-001

PLEASE NOTE

The following use instructions are broad to address multiple applications. We recommend testing for product compatibility with your process. Please contact our Tech Team at (909) 546-1160 with any questions.

OPTION #3: Blend 10-25% Duratec 904-001 into the tooling gelcoat for a gelcoat upgrade. This will improve the flow and spray characteristics of tooling gelcoat.

- 1 Catalyze with full strength MEKP catalyst at 2% (about 20 milliliters per quart).
- 2 Spray at least 2 passes over the repair, building up an additional 8 mils or more. Be sure to get back onto the first passes while they are sticky. Cover all the previously coated area. Feather the edge of the repaired area.

Once surface cure is sandable (approx. 2-4 hours) sand as outlined below to cut surface and allow full cure.

Sand

Sand when the surface has cured enough to not clog your paper. Start with the finest grit that is reasonable for the surface finish. With a good finish starting with 400 grit is possible.

The surface must be open for at least 8 hours between initial sanding and polishing. The open time allows for styrene release and full cure.

Sand with progressively finer grits like 400, 600, 800, 1000. Compound and polish with products formulated for gelcoat like Aqua Buff 1000 and Aqua Buff 2000.

Cure Times

Duratec High Gloss Additive is an air-cure product. Each gelcoat manufacturer and color option will have a different cure time. Those cure times, combined with factors like ambient temperature, humidity, catalyst ratio, and mil depth can result in a spectrum of cure times. Some surfaces will be ready within two hours, others may take more than 24-hours for full cure. Avoid spraying in temperatures below 64°F, and where possible, increase heat near part to improve cure time.

WWW.DURATEC1.COM • 909-546-1160 • HAWKEYESALES@HAWKEYEIND.COM • PO BOX 415, BLOOMINGTON, CA 92316

Limited/ warranty statement: Our products are intended for sale to industrial and commercial customers. We request that customers inspect and test our products before use and satisfy themselves as to contents and suitability. Nothing herein shall constitute a warranty, expressed or implied, including any warranty of merchantability or fitness, nor is protection from any law or patent to be inferred. All patent rights are reserved. The exclusive remedy for all proven claims is replacement of our materials and in no event shall we be liable for special, incidental or consequential damages.

www.duratec1.com



DURATEC CLEAR HI-GLOSS ADDITIVE

TROUBLESHOOTING | PRODUCT #904-001

Problem	Cause	Solution
1:1 Blend with gelcoat fails to cure	Possible incompatibility between additive and gelcoat.	Check both products separately for cure; if ok, the products are not compatible.
	High humidity.	Apply heat or spray in controlled humidity environment.
	Cool temperatures.	Spray in controlled temperature environment.
	Improper catalyst used.	Ensure using full strength catalyst at the recommended 2% ratio.
Fisheyes	Possible incompatibility between additive and gelcoat.	Check both products separately for cure; if ok, the products are not compatible.
	Air contamination. (The lower viscosity of the additive/gel coat blend increases the susceptibility to fisheyes).	Check water and oil filtration in the air line.